

## **System Components**

UL EX-4510 12-1-03 Page 1-18



## **Safety Relief Valve**

The safety relief valve is used to relieve the nitrogen pressure in the actuation line after the system has been actuated by an ANSUL AUTOMAN II-C release. After agent discharge, pulling the ring on the relief valve can relieve the pressure in the line.

Component	Material	Approvals
Safety Relief Valve	Brass	UL Listed ULC Listed FM Approved

Shipping Assembly Part No.	Description	
15677	Safety Relief Valve	

