VESDA VLF for Rail Applications

VLF-500



The fundamental nature of train operation means that there is an inherent risk of fire. High power, high inertia systems, "as built" and introduced fuel loads combine to create fire risks. Trains are an evacuation challenge, often containing large numbers of occupants in a moving platform, complicating egress. High airflows and contaminants further challenge the longevity and performance of smoke detection systems in rolling stock. Robust and reliable operation and the earliest possible detection of smoke is key to the prevention of service interruption, threats to life safety, and loss of assets and business reputation.

The VESDA VLF-500 is a very early warning smoke detector designed to protect small, business-critical environments of less than 500 m² (5380 sq. ft.). It can detect smoke reliably at the very early stages of fire development and initiate appropriate response measures to prevent losses, damage and ensure business continuity. By providing reliable detection, and simple and cost-effective maintenance, VESDA VLF-500 provides optimal protection of railcars.

The detector works by continually drawing air into sampling holes in a pipe network. The air is filtered and passed into a detection chamber where light scattering technology detects the presence of very small amounts of smoke. Detector status information is communicated on the detector display and via relays or optional interface cards.

Out-of-the-box operation

The VLF can be installed and commissioned out-of-the-box without the need for a special interface or software programming tools.

In operation, the unique Smoke DialTM display provides the user with an instant understanding of a smoke event, even from a distance. Should a fault occur, the user simply opens the field service door and activates the Instant Fault Finder feature to determine the specific fault condition. This information can then be passed onto their fire service company, ensuring that service technicians arrive onsite fully prepared.

Ultrasonic Flow Sensing

The patent-pending Ultrasonic Flow Sensing used in the VLF provides a direct reading of the sampling pipe flow rate. The system is immune to air temperature and pressure changes and is unaffected by contamination. The VLF is the first air sampling smoke detector to use ultrasonic flow sensing.

Features

- Out-of-the-Box Installation and Commissioning
- · Ultrasonic Airflow Sensing
- · Laser-Based Absolute Smoke Detection
- · Pre-engineered pipe network designs
- · Programmable Alarm Thresholds
- · Clean air barrier optics protection
- · Instant Recognition Display
- Instant Fault Finder™
- AutoLearn™ Smoke
- AutoLearn™ Flow
- Field Service Access Door
- Multiple Event Logging in separate logs
- Event log up to 18000 events
- · Offline/online configuration capability
- Up to 500 m² (5380 sq. ft.) coverage*

Listings/Approvals

- UL 94V0
- NF F16-101
- DIN 5510-2
- EN 50155
- SIL 2 as per IEC 61508 (2010)
- EN 54-20
 - Class A (30 holes / 0.05% obs/m)
 - Class B (30 holes / 0.15% obs/m)
 - Class C (30 holes / 0.32% obs/m)

Classification of any configuration is determined using ASPIRE.

Regional approvals listings and regulatory compliance vary between VESDA product models. Refer to www.xtralis.com for the latest product approvals matrix.



VESDA VLF for Rail Applications

Specifications

Input Power

24V DC Nominal (18-30 V DC) Current @ 24 VDC: 410 mA nominal, 490 mA in alarm

Note: a DC/DC power converter shall be used to power-up the unit

from the railcar power output.

1 x 50 m (150 ft) (Max. 24 holes)

PSU filter (VSP-725) must be installed on each VLF-500 detector

Dimensions (W x H x D) 256 mm x 183 mm x 92 mm (10 in x 7 in x 3 in)

Weight Approx. 2 kg (4.4 lbs)

IP Rating

Mounting Upright, inverted or horizontal

Operating Conditions[†]

Temperature Class T3 as per EN 50155 Ambient: -25°C to 70°C (-13°F to 158°F) Tested to Sampled Air: -20°C to 60°C (-4°F to 140°F) 40°C Storage: 5% to 95% RH, non-condensing

Humidity:

Maximum pipe lengths:

Sampling Network

2 x 30 m (90 ft) per branch (Max. 12 holes per branch) Sampling Hole Options: Pre-Engineered Option or Maximum Pipe length in accordance with Pipe Modelling Design Tool (ASPIRE™)

Air Inlet Pipe

Accepts both metric and American standard pipe sizes

Metric: 25 mm (1.05 in.) American Pipe: IPS 21 mm (3/4 in.). Flexible 21.6 mm (0.85 in.)

Up to 500 m² (5380 sq. ft.) depending on local codes and standards

Relay Outputs

3 changeover relays (Fire 1, Action, Fault), Contacts rated 2A @ 30 VDC (max). NO/NC Contacts

3 x 25 mm (1 1 / $_{16}$ in.) cable entries (1 rear entry, 2 top entry)

Cable Termination

Screw Terminals 0.2-2.5 mm² (30-12 AWG)

Shown in Terminal Block Connections diagram, to right, plus an RS232 Programming Port. General Purpose Input (GPI) interface offers: Reset, Disable, Standby, Alarm set 1, Alarm set 2 and External Input functions.

Alarm Threshold Setting Range

Alert, Action 0.025 - 2.00% obs/m (0.008 - 0.625% obs/ft) Fire 1, Fire 2 0.025 - 20.00% obs/m (0.008 - 6.25% obs/ft) Individual Alarm Delays 0-60 seconds

Two Alarm Threshold Settings Either time or GPI based

• Fault and Disabled Indicators • 4 Alarm State Indicators · Smoke Level Indicator • Instant Fault Finder

• Reset, Disable and Test Controls

· Smoke and Flow AutoLearn Controls

Event Log

Up to 18000 events, time and date stamped in separate, non-volatile, logs for:

Smoke Level, Flow Level, Detector Status and Faults

Autol earn Smoke & Flow

· Automatically set acceptable alarm thresholds for both smoke and flow levels

• Minimum 15 minutes, maximum 15 days (default 14 days)

• During AutoLearn, thresholds are NOT changed from pre-set values

Warranty Period

2 years

Ordering Information:

VLF-500-00 VESDA VLF. European language set. English display labels VLF-500-01 VESDA VLF. European language set. International display labels VLF-500-02 VESDA VLF. English + Asian language set. International display labels VLF-500-04 VESDA VLF. English + Russian language set. International display labels VLF-500-05 VESDA VLF. English + Eastern Euro language set. International display labels

VSP-725 VESDA PSU Filter VSP-850-R (Red) In-line Filter VSP-850-M (Metal) In-line Filter

VSP-855-20 In-line Filter Elements (pack of 20) VIC-010 VESDAnet Interface Card VIC-020 Multifunction Control Card (MCC)

VIC-030 Multifunction Control Card (MCC) with Monitored Powered Output (MPO)

VSP-005 Filter Cartridge

VSP-715 Aspirator for VESDA VLF-500

The contents of this document are provided on an "as is" basis. No representation or warranty (either express or implied) is made as to the completeness, accuracy or reliability of the contents of this document. The manufacturer reserves the right to change designs or specifications without obligation and without further notice. Except as otherwise provided, all warranties, express or implied, includin on any implied warranties of merchantability and fitness for a particular purpose are expressly excluded. Xtrails, the Xtrails logo, The Sooner You Know, VESDA-E, VESDA, ICAM, ECO, OSID, HeiTel, ADPRO, IntrusionTrace, LoiterTrace, ClientTrace, SmokeTrace, XOa, XOh, Trace, iCommand, iRespond, iCommission, iPIR, and FMST are trademarks and/or registered trademarks of Xtrails and/or lot subsidialries in the United States and/or other countries. Other brand names mentioned herein are identification purposes only and may be trademarks of their respective holder(s). Your use of this document does not constitute or create a licence or any other right to use the name and/or trademarks and/or label.

This document is subject to copyright owned by Xtralis. You agree not to copy, communicate to the public, adapt, distribute, transfer, sell, modify or publish any contents of this document without the express prior written consent of Xtralis.

Doc. no. 29874 00

VLF-500

Display

The display provided to the user includes a Smoke Dial™ and alarm and status indicators.



When the field service access door is open, the user has access to the RESET C DISABLE , Fire Test , AutoLearn and Instant Fault Finder functions. When the Instant Fault Finder function is activated, the Smoke Dial™ converts to a fault indicator, with the dial segment numbers corresponding to the faults listed below.

Legend of fault indicators

1 Filter

6 External Device/PSU


2 Aspirator 3 High flow 7 Interface card 8 Field wiring

4 Low flow 5 n/a

9 AutoLearn Fail

Detector failure

Terminal Block Connections



Approvals Compliance

Please refer to the Product Guide for details regarding compliant design, installation and commissioning.

