CO$_2$ Component Description

Reset Tool Assembly

DESCRIPTION

The Reset Tool Assembly, P/N 81-129958-001 is designed to reset the actuating pin on the Explosion Proof Electric Control Head, P/N 81-100000-001.

INSTALLATION

Use the following procedures to reset the actuating pin on the Explosion Proof Electric Control Head.

1. Back the screw out of the body of the reset tool assembly so that approximately 3/4 in. (20 mm) of the screw is exposed from the body. See Figure 2.

2. Hand tighten the reset tool assembly into the swivel nut on the explosion proof electric control head.

⚡ **CAUTION**	**Do not use a wrench to tighten the reset tool assembly onto the swivel nut as you may damage the threads.**

3. Using a non-marring wrench, slowly tighten the screw on the reset tool assembly until you hear an audible click. Tighten the screw an additional 1/4-turn.

4. Loosen the screw and then remove the reset tool assembly from the swivel nut.

⚡ **WARNING**	**Care should be taken to ensure that the actuating pin is in the set position when attaching the control head to the cylinder or the stop/directional valve. Accidental system discharge could occur, which could cause property damage, personal injury and/or death.**

ORDERING INFORMATION

| Part Number	Description
81-129958-001	Reset Tool Assembly

Figure 1. Reset Tool Assembly, P/N 81-129958-001

Figure 2. Installing the Reset Tool Assembly

Kidde is a registered trademark of Kidde-Fenwal, Inc.